









INSTALLATION INSTRUCTIONS



Standard Rebounder Assembly



Parts List:

Tubing:		Fittings:		Others:			
4	Part A	2	10-8 Kee Klamp (1)	3	2" i.d. PVC sleeves	1	Vinyl Skirt
10	Part B	2	15-8 Kee Klamp (2)	1	Pole Cap	10	Releasable Ty-Raps
3	Part C	2	25-8 Kee Klamp (3)	1	Rebound Net	1	Webbing Strap
2	12" Braces	2	12-8 Special Fittings	30	Bungee Cords	1	Set Screw Key
				20	Adjustable Straps		

1. Sink PVC sleeves to a depth of 2' in concrete that is at least 3' deep; as shown on the illustration. Note that the center pole is set back from the two end poles.



2. Assemble bottom bar over the holes as a guide. Lift off, lay down and finish assembly of frame on the ground. Use a set screw key to secure poles in fittings. Be sure the whole frame, including the 1' set backs, is assembled before installing the net.
3. To install netting, fasten frame along sides and top using bungee cords, hooking every 8 mesh square. Put tension on netting using 20 adjustable straps spaced evenly along the bottom.
4. Attach vinyl skirt at bottom using ty-raps. Thread webbing into netting at 3' height to simulate tennis net height